


User's Manual

MR1420S MR1420W

MP3-COMPATIBLE
IN-DASH MARINE CD RECEIVER

BOSS
marine



BOSS
marine

MR1420S • MR1420W
MP3-COMPATIBLE IN-DASH CD RECEIVER
10.2006

tech support: www.bosssaudio.com/support


   10 R - 02 1397

BOSS
AUDIO SYSTEMS

BOSS Audio Systems • 3451 Lunar Court • Oxnard, CA 93030
www.bosssaudio.com
800.999.1236

BOSS
AUDIO SYSTEMS

1. BUTTONS LOCATION AND FUNCTIONS



EN

1. Panel Release Button
2. Mute Button
3. CD Eject Button
4. Audio Button
5. Display Button / ID3 Information Button
6. Local / Distant Button
7. Preset Memory Buttons
8. Mono / Stereo Button
9. Scan Button
10. Volume Knob
11. MP3 Menu Button & Automatically Store / Preset Scan Button
12. Power Button
13. Band/Loudness Button / MP3 Enter Button
14. Tuning Up/Down & Track Up / Down Buttons
15. Source Button
16. Preset Equalizer Button
17. Folder Down / Up Buttons
18. Aux In Jack

PT

1. Tecla para remover o painel frontal
2. Tecla Mute
3. Tecla para ejetar o disco
4. Tecla de ajuste de áudio
5. Tecla Display / informação MP3-ID3
6. Tecla Local/Distante
7. Teclas de memória de estações
8. Tecla estéreo/mono
9. Tecla Scan
10. Controle de volume
11. Tecla Menu e memorização automática (As) / Preset Scan (Ps)
12. Tecla Ligar/desligar
13. Tecla Banda/Loudness/MP3 Enter
14. Teclas de sintonização de estações / mudança de faixas de música
15. Tecla Source
16. Tecla Equalizador pré-programado
17. Tecla Seleção de pastas
18. Entrada Auxiliar

DE

1. Entriegel-Taste Bedienteil
2. Stumm-Taste
3. CD-Auswurf Taste
4. Audio-Taste
5. Display-/ ID3-Taste
6. Local / Distant-Taste
7. Senderspeichertasten
8. Mono / Stereo-Taste
9. Scan- Taste
10. Lautstärkenregler
11. AMS Taste / MP3 Suchlauf Taste
12. Einschalt-Taste
13. Frequenzband-Taste / MP3 Eingabe-Taste
14. Titel AUF / AB - Taste
15. Source-Taste
16. PEQ-Taste
17. Folder Down / Up - Taste
18. Front-Audio-Anschluss

ES

1. Extracción del panel frontal
2. Mute / silenciamiento de sonido instantaneo.
3. Apertura del panel motorizado y expulsión del disco
4. Tecla Audio
5. Selección información Display/ID3 TAG muestra
6. Botón Distancia/Local
7. Botones de estaciones memorizadas
8. Botón selección mono/estéreo
9. Botón De Búsqueda
10. Botón De Volumen
11. Menú del Sistema de Memorización Automática de emisoras / selección de memorias
12. Encendido/Apagado
13. Selector Bandas / Bajos/MP3
14. Botón de selección de emisoras & banda de música
15. Selección modos Radio/CD/Entrada auxiliar
16. Tecla de ecualización
17. Botón de selección de carpeta/folder
18. Entrada de auxiliar

FR

1. Bouton De Déclenchement Du Panneau
2. Bouton D'assourdissement
3. Bouton Ejection D'un Cd
4. Bouton De Sélection Audio / Entrée De MP3
5. Bouton D'écran / Affichage D'information Sur Les Disques MP3
6. Bouton Local/distant
7. Boutons Des Stations Préréglées (m1 ~m6)
8. Bouton De La Stéréo Du Mono
9. Bouton Du Scanner
10. Bouton De Volume
11. Bouton De Menu & Bouton De Stockage Des Stations Dans La Mémoire
12. Bouton D'alimentation
13. Bouton De Bande / Entrée De MP3
14. Bouton De Recherche Des Stations/pistes : En Avant / En Arrière
15. Bouton De Régime
16. Bouton De PEQ
17. Dossier En Le Bouton/ Vers Le Haut Le Bouton
18. Aux A Jack

IT

1. Tasto Rilascio Frontalino
2. Tasto Mute
3. Tasto Eject
4. Audio Controlla
5. Tasto Display/ID3 (informazioni)
6. Bottone Distanza Locale
7. Tasti Stazioni Memorie Preimpostate
8. Bottone di Stereo/Mono
9. Tasto Scan
10. Tasto Volume
11. Tasto Menu & AS/PS
12. Tasto Power
13. Tasto Banda/Forte & Enter MP3
14. Tasto sintonizzazione su/gui & traccia su/gui
15. Tasto Mode
16. Bottone di equalizzatore preprogrammato
17. Bottone di Cartella su/gui
18. Entrada Aux

2. HANDLING COMPACT DISCS

MOISTURE CONDENSATION

On a rainy day or in a very damp area, moisture may condense on the lenses inside the unit. Should this occur, the unit will not operate properly. In such a case, remove the disc and wait for about an hour until the moisture has evaporated.

NOTES ON CDs


- 1. A dirty or defective disc may cause sound dropouts while playing. To enjoy optimum sound, handle the disc as follows.
Handle the disc by its edge. To keep the disc clean, do not touch the surface (P.1).
- 2. Do not stick paper or tape on the disc (P.2).
- 3. Do not expose the discs to direct sunlight or heat sources such as hot air-ducts, or leave them in a car parked in direct sunlight where there can be a considerable rise in temperature inside the car (P.3).
- 4. Before playing, clean the discs with an optional cleaning cloth. Wipe each disc from the center out (P.4).
- 5. Do not use solvents such as benzene, thinner, commercially available cleaners, or antistatic spray intended for analog discs.



NOTES ON DISCS


If you use the discs explained below, the sticky residue can cause the CD to stop spinning and may cause malfunction or ruin your discs.
Do not use second-hand or rental CDs that have a sticky residue on the surface (for example, from peeled-off stickers or from ink, or glue leaking from under the stickers).

**There are paste residue.
Ink is sticky (P.5).**




Do not use CDs with old labels that are beginning to peel off.

**Stickers that are beginning
to peel away, leaving a
sticky residue (P.6).**



Do not use your CDs with labels or stickers attached.

Labels are attached (P.7).



Do Not Use Special Shape CDs

Be sure to use round shape CDs only for this unit and do not use any special shape CDs. Use of special shape CDs may cause the unit to malfunction.(P.8).



Be sure to use CDs with disc mark




Only for this unit.

CD-Rs and CD-RWs which have not undergone finalization processing cannot be played. (For more information on finalization processing, refer to the manual for your CD-R/CD-RW writing software or CD-R/CD-RW recorder.) Additionally, depending on the recording status, it may prove impossible to play certain CDs record on CD-R or CD-RW.

3. INSTALLATION

- Before finally installing the unit, connect the wiring temporarily and make sure it is all connected up properly and the unit and system work properly.
- Use only the parts included with the unit to ensure proper installation. The use of unauthorized parts can cause malfunctions.
- Consult with your nearest dealer if installation requires the drilling of holes or other modifications of the vehicle.
- Install the unit where it does not get in the driver's way and cannot injure the passenger if there is a sudden stop, like an emergency stop.
- If installation angle exceeds 30° from horizontal, the unit might not give its optimum performance.




- Avoid installing the unit where it would be subject to high temperature, such as from direct sunlight, or from hot air, from heater, or where it would be subject to dust dirt or excessive vibration.
- Be sure to remove the front panel before installing the unit.

DIN FRONT/REAR-MOUNT


This unit can be properly installed either from “Front” (conventional DIN Front-mount) or “Rear” (DIN Rear-mount installation, utilizing threaded screw holes at the sides of the unit chassis). For details, refer to the following illustrated installation methods A and B.

DIN FRONT-MOUNT (Method A)

Installation the unit




1. Dashboard
 2. Holder
- After inserting the half sleeve into the dashboard, select the appropriate tab according to the thickness of the dashboard material and bend them inwards to secure the holder in place.
3. Screw



1. Dashboard
 2. Nut (5mm)
 3. Spring washer
 4. Screw (5x15mm)
 5. Screw
 6. Support Strap
- Be sure to use the support strap to secure the back of the unit in place. The strap can be bent by hand to the desired angle.
7. Plain washer

Removing the unit



- a. Frame
- b. Insert fingers into the groove in the front of frame and pull out to remove the frame. (When re-attaching the frame, point the side with a groove down wards and attach it.)
- c. Insert the levers supplied with the unit into the grooves at both sides of the unit as shown in figure until they click. Pulling the levers makes it possible to remove the unit from the dashboard.


Trim Plate Installation:

Push the trim plate against the chassis until it is fitted.

You must do this before you install the front panel, otherwise it can't be attached.

DIN REAR-MOUNT (METHOD B)

Installation using the screw holes on the sides of the unit.
Fastening the unit to the factory radio mounting bracket.



1. Select a position where the screw holes of the bracket and the screw holes of the main unit become aligned (are fitted) and tighten the screws at 2 places on each side.
2. Screw
3. Factory radio mounting bracket.
4. Dashboard or Console
5. Hook (Remove this part)

Note: the mounting box, outer trim ring, and half-sleeve are not used for method B installation.


4. DETACHABLE CONTROL PANEL (D.C.P.)

Removing The Detachable Control Panel (D.C.P.).



1. Turn the power off
2. Press the D.C.P. release button
3. Remove the D.C.P.


Attaching the DCP



1. Attach the panel at the right side first, with point B on the main unit touching point A on the D.C.P. (As shown on the digram).
2. Then press the left side of D.C.P. onto the main unit until a “click” sound is heard.

CAUTION



- DO NOT insert the D.C.P from the left side. Doing so may damage it.
- The D.C.P can easily be damaged by shocks. After removing it, place it in a protective case and be careful not to drop it or subject it to strong shocks.
- When the release button is pressed and the D.C.P is unlocked, the car's vibrations may cause it to fall. To prevent damage to the D.C.P, always store it in a protective case after detaching it.
- The rear connector that connects the main unit and the D.C.P is an extremely important part. Be careful not to damage it by pressing on it with fingernails, pens, screwdrivers, etc.



Note:

If the D.C.P is dirty, wipe off the dirt with soft, dry cloth only. And use a cotton swab soaked in isopropyl alcohol to clean the socket on the back of the D.C.P.

5. WIRING DIAGRAM (20 PIN HARNESS PLUG)



PIN	WIRE COLOR	FUNCTION/LABEL
1	GRAY/BLACK	RIGHT FRONT SPEAKER (-)
2	GRAY	RIGHT FRONT SPEAKER (+)
3	VIOLET	RIGHT REAR SPEAKER (-)
4	VIOLET/BLACK	RIGHT REAR SPEAKER (+)
5	GREEN	LEFT REAR SPEAKER (+)
6	GRAY/VIOLET	LEFT REAR SPEAKER (-)
7	RED	(IGNITION/ACC)
8	BLACK	REAR SEAT AMP LINE OUT COMMON
12	RED	RIGHT REAR AMP LINE OUT
13	WHITE	LEFT REAR SPEAKER (-)
14	WHITE/BLACK	LEFT REAR SPEAKER (+)
15		
16	BLUE	POWER ANTENNA
17	YELLOW	BATTERY (-)
18	BLACK	CHASSIS GROUND
19	WHITE	LEFT FRONT PRE-AMP LINE OUT
20	RED	RIGHT FRONT PRE-AMP LINE OUT
21	BLACK	FRONT AMP LINE OUT COMMON
22	WHITE	LEFT REAR PRE-AMP LINE OUT



#	KABELFARBE	FUNKTION / ETIKETT
1	GRAU/SCHWARZ	RECHTER VORDERLUPTSPEICHER (-)
2	GRÜN	RECHTER VORDERLUPTSPEICHER (+)
3	VIOLETT	RECHTER RUCKLUFTSPEICHER (-)
4	ROT/SCHWARZ	RECHTER RUCKLUFTSPEICHER (+)
5		
6	GRÜN	LINER RUCKLUFTSPEICHER (+)
7	GRÜN/SCHWARZ	LINER RUCKLUFTSPEICHER (-)
8	ROTT	Z-DRUCK HORN
9	SCHWARZ	RUCKPUMPENANSSCHLUSS AUS
10	ROTT	RUCKPUMPENANNSCHLUSS AUS
11	WEISS	LINER VORDERLUPTSPEICHER (-)
12	WEISS/SCHWARZ	LINER VORDERLUPTSPEICHER (+)
13		
14	BLAU	MOTORISIERTE ANTENNE
15	GELB	BATTERIE (-)
16	SCHWARZ	GEHÄUSE
17	WEISS	HINTERER VORDERSTÄNDERANSCHLUS
18	ROTT	VORDERE VORDERSTÄNDERANSCHLUS
19	SCHWARZ	VORDERE VORDERSTÄNDERANSCHLUS NORMAL



CH	COULEUR DU CABLE	FONCTION / MARQUE
1	GRIS/NOIR	ENCEINTE AVANT DROIT (L)
2	GRS	ENCEINTE AVANT DROIT (A)
3	JAUNE	ENCEINTE AVANT DROIT (L)
4	VIOLET/NOIR	ENCEINTE ARRIERE DROIT (L)
5		
6	VERT	ENCEINTE ARRIERE GAUCHE (L)
7	VERT/NOIR	ENCEINTE ARRIERE GAUCHE (A)
8	ROUGE	ALLUMAGE (A)
9	NOIR	SORTIE COMMUNE ARRIERE PRE-AMPLI
10	ROUGE	SORTIE PRE-AMPLI ARRIERE DROIT
11	BLANC	SORTIE PRE-AMPLI ARRIERE GAUCHE
12	NOIR/BLANC	ENCEINTE AVANT GAUCHE (L)
13		
14	BLEU	PUISSANCE ATTENU
15	JANNE	BATTERIE (L)
16	NOIR	CHASSIS TERRE
17	BLANC	SORTIE AVANT GAUCHE PRE-AMPLI
18	ROUGE	SORTIE AVANT DROITE PRE-AMPLI
19	NOIR	SORTIE NOIR COMMUNE PRE-AMPLI
20	BLANC	SORTIE PRE-AMPLI ARRIERE GAUCHE



PN	CORPO FID	FUNÇÃO	ETIQUETA
1	CANAPRETO	ALTO FALANTE DIANTERO DIREITO (+)	
2	CINZA	ALTO FALANTE DIANTERO DIREITO (+)	
3	COLETA	ALTO FALANTE TRASERO DIREITO (+)	
4	MOLETA PRETO	ALTO FALANTE TRASERO DIREITO (+)	
5			
6	VERDE	ALTO FALANTE TRASERO ESQUERO (+)	
7	VERDE PRETO	ALTO FALANTE TRASERO ESQUERO (+)	
8	CANAPRETO		
9	PRETO	SAIDA PRE-AMP TRASERA (FO COMUM)	
10	VERMELHO	SAIDA PRE-AMP TRASERA DIREITA	
11	BRANCO	SAIDA PRE-AMP TRASERO ESQUERO (+)	
12	BRANCO PRETO	SAIDA PRE-AMP TRASERO ESQUERO (+)	
13	AZUL	ALTO FALANTE DIANTERO ESQUERO (+)	
14			
15	AMARELO	Isolado (+)	
16	PRETO	MASSA (+) TERÇA	
17	BRANCO	SAIDA PRE-AMP TERÇA	
18	VERMELHO	SAIDA PRE-AMP FRENTE DIR	
19	PRETO	SAIDA PRE-AMP FRENTE (FO COMUM)	



FIN	COLOR DE CABLE	FUNCION
1	GRIS NEGRO	ALTAVOZ FRONTAL DERECHO (1)
2	GRIS NEGRO	ALTAVOZ FRONTAL DERECHO (2)
3	VERDE	ALTAVOZ FRONTAL DERECHO (3)
4	VERDE	ALTAVOZ FRONTAL DERECHO (4)
5	VERDE	ALTAVOZ TRASERO DERECHO (1)
6	VERDE	ALTAVOZ TRASERO DERECHO (2)
7	VERDE	ALTAVOZ TRASERO DERECHO (3)
8	VERDE	ALTAVOZ TRASERO DERECHO (4)
9	VERDE	ALTAVOZ TRASERO DERECHO (5)
10	ROJO	IGNICION (ACC)
9	NEGRO	LÍNEA DE SALIDA PRE-AMP TRASERA
10	ROJO	LÍNEA DE SALIDA PRE-AMP TRASERA DERECHA
11	NEGRO	LÍNEA DE SALIDA PRE-AMP TRASERA IZQUIERDA
12	BLANCO	ALTAVOZ FRONTAL IZQUIERDO (1)
13		
14	AZUL	ALIMENTACION DE ANTENA
15	AMARILLO	BATERIA
16	NEGRO	CHASIS DE TIERRA
17	BLANCO	SALIDA - PRE-AMP FRONTAL QUERDO
18	ROJO	SALIDA - PRE-AMP FRONTAL DERECHA
19	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
20	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
21	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
22	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
23	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
24	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
25	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
26	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
27	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
28	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
29	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
30	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
31	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
32	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
33	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
34	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
35	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
36	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
37	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
38	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
39	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
40	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
41	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
42	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
43	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
44	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
45	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
46	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
47	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
48	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
49	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
50	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
51	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
52	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
53	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
54	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
55	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
56	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
57	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
58	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
59	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
60	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
61	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
62	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
63	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
64	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
65	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
66	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
67	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
68	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
69	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
70	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
71	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
72	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
73	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
74	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
75	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
76	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
77	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
78	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
79	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
80	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
81	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
82	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
83	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
84	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
85	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
86	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
87	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
88	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
89	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
90	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
91	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
92	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
93	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
94	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
95	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
96	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
97	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
98	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
99	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO
100	BLANCO	SALIDA - PRE-AMP FRONTAL COMBINADO



FIN	COLORE CAVO	FUNZIONE
1	GRIGIO/NERO	CASSA ANTERIORE DESTRA (L+)
2	GRIGIO	CASSA ANTERIORE DESTRA (+)
3	VIOLO	CASSA ANTERIORE SINISTRA (-)
4	VIOLO/NERO	CASSA POSTERIORE DESTRA (L+)
5	VERDE	CASSA POSTERIORE SINISTRA (+)
6	TENDINEGGIO	CASSA POSTERIORE SINISTRA (L+)
8	ROSSO	ACCENSIONE TAKE OFF (NEZIONE)
9	NERO	MESSA TERRA
10	ROSSO	AMPLIFICATORE CASSA POST. DESTRA
11	BIANCO	CASSA ANTERIORE SINISTRA (+)
12	BIANCO/NERO	CASSA ANTERIORE SINISTRA (-)
13		
14	BLU	ANTENNA
15	BIANCO	BATTERIA (+)
16	NERO	MESSA TERRA
17	BIANCO	USCITA FRONTALI A SINTONO PRE-AMP
18	ROSSO	USCITA FRONTALI DESTRO PRE-AMP
19	ROSSO	USCITA FRONTALI SINISTRO PRE-AMP
20	BIANCO	AMPLIFICATORE CASSA POST. SX

6. BASIC OPERATIONS

1) PANEL RELEASE BUTTON (REL)

Press this button to remove the control panel.

12) POWER ON/OFF BUTTON

Press this button to turn on or off the power.

5) DISPLAY BUTTON (DISP)

Press this button briefly, the LCD will display the clock for about 2 seconds, then return to previous display mode.

Clock Adjustment

Under clock display mode, press DISP button until the LCD flashes, press Tuning Up Button to adjust hour and Tuning Down Button to adjust minute.

15) SOURCE BUTTON (SOURCE)

Press this button to select Radio and CD modes.


The available selections depends on version:

Radio CD Player

Radio > CD > AUX in


18) FRONT AUXILIARY INPUT JACKS

Connect the external signal to AUX in jack located at the front of the panel, then press **SOURCE** button to select Aux mode. Press **SOURCE** Button again to cancel Aux Mode and return to previous mode.



RESET BUTTON

The RESET button is located on the main unit (as shown on the diagram). To press it vertically with a ballpoint pen or metal object will activate it. The reset button is to be activated for the following reasons:



- Initial installation of the unit when all wiring is completed.
- All the function buttons do not operate.
- Error symbol on the display.

Note: If the unit cannot function normally after resetting, please use a cotton swab soaked in isopropyl alcohol to clean the socket on the back of the control panel.

7. AUDIO OPERATIONS

10) VOLUME KNOB

Turn this knob to adjust desired volume level.

4) AUDIO BUTTON

Press this button to select desired audio function.

ORDER OF FUNCTION:

VOLUME(VOL) -> BASS(BAS) -> TREBLE(TRE) -> BALANCE(BAL) -> FADER(FAD)

While the selected function is displayed, turn Volume Knob to adjust the level within 5 seconds, otherwise the unit will return to volume adjustment mode.

2) MUTE BUTTON (MUTE)

Press this button to mute the sound. Press it again to resume listening.

16) PRESET EQUALIZER BUTTON (EQ)

Press this button to toggle the following EQ settings:

☐ **FLAT->CLASSICS->POP M->ROCK M->DSP OFF**

At DSP OFF mode, EQ will be controlled by Bass/Treble setting.

13) BAND/LOUDNESS BUTTON (BAND/LOUD)

Press the Band/Loudness Button for couple of seconds to switch the loudness on or off. When Loudness is on, display will show 'Loud On' for a few seconds.

8. RADIO OPERATIONS

11) AUTO MEMORY STORE/PRESET SCAN BUTTON (AS/PS)

1. PRESET SCAN: Press AS/PS button briefly to enter Preset Scan mode, it will scan all the preset stations in the memories, you can hear that it will stay on each station for about 5 seconds.
2. AUTO MEMORY STORE: Press AS/PS button for couple of seconds to enter Auto Store mode, this feature will automatically scan the current band and enter up to 6 strongest stations into the 6 preset memories. To stop Auto Store & Scan, press the AS/PS button again.

7) STATION PRESET BUTTONS (M1-M6)

1. Press these buttons briefly to recall the stored stations in the selected band.
2. Presetting stations manually, Press the BAND button to select the band for the stations to be preset. Use Tuning Up/Down to tune in the stations to be preset. Press the Preset button at which you want to store the station for at least 2 second. The preset number will appear on the display accompanied by a beep, this indicates that the station has been stored into memory.

13) BAND/LOUDNESS BUTTON (BAND/LOUD)

This a dual function button. Press this button shortly to change between BAND FM1, FM2, FM3 or AM bands. Press this button for couple of seconds to turn Loudness function on or off.

14) TUNING / SEEK UP AND TUNING / SEEK DOWN BUTTONS

1. Press these buttons briefly, and the unit will operate in AUTO SEARCH tuning mode, the radio will tune up or down to the next station and remain on that station.
2. Press these buttons for more than 2 seconds, operate as MANUAL SEARCH buttons, under this mode the tuning frequency will advance up or down rapidly when the button is pressed. If the buttons are not pressed within 3 seconds, they will return to auto search mode.

8) MONO STEREO BUTTON (MO/ST)

When you receive a station, "ST" on the display will be on. Press this button to enter Mono mode.

9) SCAN BUTTON(SCAN)

Press this button, the radio will tune up to search stations, the available stations will blink and stay on the display for a few seconds.

6) LOCAL/DISTANT BUTTON (LOC)

During station tuning, this button allows you prior to access strong local station only (Local mode), or to access a wider range of using distant mode (DX). When powered on, DX mode will be defaulted automatically; Press LOC button briefly to select Local mode and "LOCAL" symbol on the LCD will light up for a few seconds.

9. CD OPERATIONS

M1) PAUSE BUTTON (PAUSE)

Press this button to pause CD play, press again to release pause.

M2) SCAN BUTTON (SCAN)

Press this button, the first 10 seconds of each track will be played sequentially until this button is pressed again, then normal play will resume at the current track.

M3) REPEAT BUTTON (REPEAT)

Press this button, the current track will be played repeatedly until this button is pressed again.

M4) SHUFFLE BUTTON (SHUFFLE)


Press this button to play all tracks on CD in random. Press again to deactivate it.

14) TRACK UP AND TRACK DOWN BUTTON

Press the Track Up Button to skip to the next track or previous track. Press the Track Down button during play will return to the beginning of the current track, press it one more time to skip to previous skip. Press and hold Track Up/Down Button to fast forward or fast reverse. CD player starts playing when you release the button.

EJECT BUTTON ▲

Press this button to eject the CD from the unit. The receiver will switch to radio mode automatically.



10.MP3 OPERATIONS

Notes :

- An MP3 directory is shown in this manual as "Directory", and an MP3 file is shown as "Track".
- Maximum length of file name : 28 characters.
- Maximum length of directory : 16 characters.
- Maximum number of tracks per disc : 254.
- Maximum number of directories per disc : 128.
- Sampling Frequencies support : 32KHz, 44 KHz, 48KHz.
- Bit Rates support : 64 - 320KHz including VBR.
- Supports Multi-Session recording.
- Supports CD, CDR and CDRW.
- Disc written by Packet Write (UDF) is not supported.

LOADING DISC

Insert the CD as usual, if it is an MP3 CD, the display will show "MP3 T01" then the message "READING" will appear, when disc scanning completed, the first track on the first directory will play.

- NOTE: 1) MP3 ICON turns on when a MP3 disc is playing.
2) MP3 ICON is blinking when under directory / files search mode.
3) DIR ICON turns on when the playing file is a directory.

NAVIGATING THROUGH DIRECTORIES AND TRACKS

NOTE: MP3 Directory / Track selection can be done by Volume Knob or Tune Up / Down Buttons Both operations will be described. Please skip this description if your model is not equipped with this feature.

THERE ARE FOUR WAYS TO SELECT YOUR FAVORITE TRACK / DIRECTORY

A) SEARCHING TRACK DIRECTLY

Under MP3 play mode, press MP3 MENU BUTTON once, the display shows "MP3 T*", enter the desired track number directly, then press MP3 ENTER BUTTON to confirm. The distribution of the number are listed as follow:

Number	1	2	3	4	5	6	7	8	9	0
Button	M1	M2	M3	M4	M5	M6	SUB SOURCE	TUNE DN	TUNE UP	ID3 DISPLAY

SEARCH TRACK NUMBER BY USING ENCODER VOLUME KNOB

Rotate the VOLUME KNOB to scroll through the numbers, then press MP3 ENTER BUTTON to confirm.

B) SEARCHING BY DIRECTORY OR TRACK NAME

(1) SEARCH DIRECTORY / TRACK NAME BY USING TUNE UP / DOWN BUTTON

Under MP3 Play Mode, press MP3 MENU BUTTON twice, the display shows " * " , enter the character directly. The unit searches files and directories which have the same character which is inputted by the user. The unit shows these sorted files and directories by TUNE UP / DOWN Button (TUNE DOWN First). If the selected name is directory, the user can go into the selected directory by press MP3 ENTER BUTTON and continue to search the directory or file name in the directory by TUNE UP / DOWN Button (TUNE DOWN First). The selected file can be played by pressing MP3 Enter Button

The distribution of alphabetical characters are listed as follow :

Button	M1	M2	M3	M4	M5	M6	SUB SOURCE	TUNE DN	TUNE UP	ID3 DISPLAY	SEL	VOL UP/DN
Character	A,B,C	D,E,F	G,H,I	J,K,L	M,N,O	P,Q,R	S,T,U	V,W,X	Y,Z, Space	_,.,+	Move Cursor	Next/Previous Character

(2) SEARCH DIRECTORY / TRACK NAME BY USING VOLUME KNOB

Under MP3 Play Mode, press MP3 MENU BUTTON twice, the display shows “* “. Rotate the VOLUME KNOB for selecting the character. In this Encoder Search mode, SELECT button use as move cursor. Press BAND/LOUDNESS button use as MP3 CONFIRM BUTTON. The unit searches files and directories which have the same character which is inputted by the user. The unit shows these sorted files and directories by VOLUME KNOB (ROTATE ANTI-CLOCKWISE First). If the selected name is directory, the user can go into the selected directory by press MP3 CONFIRM BUTTON and continue to search the directory or file name in the directory by VOLUME KNOB (ROTATE ANTI-CLOCKWISE First) The selected file can be played by pressing MP3 CONFIRM BUTTON.

(C) SEARCHING FROM DIRECTORY

(1) SEARCH DIRECTORY BY USING TUNE UP / DOWN BUTTON.

Under MP3 play mode, press MP3 MENU BUTTON three times, Then the first Directory name is shown. Press TUNE UP/DOWN (TUNE DOWN FIRST) to navigate through the directory list, press MP3 ENTER BUTTON to select the desired directory. The display will show “\ \ “. To select the tracks under the selected directory, by pressing TUNE UP/DOWN Buttons (TUNE DOWN FIRST) then press MP3 ENTER BUTTON to confirm when desired track is found.

(2) SEARCH DIRECTORY BY USING VOLUME KNOB

Under MP3 play mode, press MP3 MENU BUTTON three times, Then the first Directory name is shown. Rotate VOLUME KNOB counter-clockwise first to navigate through the directory list, press MP3 ENTER BUTTON to select the desired directory. The display will show “\ \ “. To select the tracks under the selected directory, by Rotating VOLUME KNOB counter-clockwise first, then press MP3 ENTER BUTTON to confirm when desired track is found.

(D) NAVIGATING THROUGH DIRECTORY BY USING M5/M6 BUTTON

Press directory up (M6) or directory down (M5) buttons to skip the current directory forward or backward by one position.

In a multi-level directories disc, the movement will take place at the current level until the last directory is reached. At this point press directory down (M5) again , it will move to the next level of directory.

ID3 TAG

Press DISPLAY button repeatedly to Display ID3 TAG information.

If the MP3 file is available with ID3 TAG, pressing the display button repeatedly will show information in the following sequence:

SONG TITLE > ARTIST> ALBUM TITLE

If any of the ID3-TAG information is not available, pressing the DISPLAY button repeatedly will show information in the following sequence:

UNKNOWN SONGNAME> UNKNOWN ARTIST> NO ALBUM TITLE

If the MP3 file is without ID3 TAG, pressing the DISPLAY button, & “NO ID3 TAG” will be displayed.

The file name & track number of the MP3 file will scroll repeatedly through the display during the playing of the MP3 file.

11. SPECIFICATIONS

EN

CD PLAYER

System	Compact disc audio system
Usable disc	Compact disc
Sampling frequency	44.1KHz
No of quantization bits	1bit
Frequency	5-20,000Hz
Number of channels	2 stereo
S/N Ratio	70dB

RADIO SECTION

FM

Frequency Range	87.5-107.9MHz
Intermediate Frequency	87.5-108 Mhz
Usable Sensitivity	10.7 MHz
Stereo Separation	Better than 15dB at S/N 30 dB
S/N Ratio	25 dB at 1KHz
	50 dB

AM/MW

Frequency Range	530-1710KHz
Intermediate Frequency	522-1620KHz
Usable Sensitivity	450KHz
S/N Ratio	Better than 45dB
	40 dB

GENERAL

Power Supply	DC 11 -14V
Polarity	Negative Ground
Speaker Impedance	4 ohms
Power Output	4x 60 Watts

REMARK :

Specifications subject to change without notice.

DE

CD PLAYER

System	Compact Disc Audio System
Abspielbare Discs	Compact Disc
Sampling-Frequenz	44,1 KHz
Anzahl Quantisierungsbits	1 bit
Frequenz	5-20.000Hz
Anzahl Kanäle	2 Stereo
Signalrauschabstand	70 dB

RADIOTEIL

FM

Frequenzbereich	87.5-107.9MHz
Zwischenfrequenz	87.5-108MHz
Nutzbare Empfindlichkeit	10.7 MHz
	Besser als 15 dB bei einem
	Signalrauschabstand von 30 dB
	25 dB bei 1 kHz
	50 dB
Stereotrennung	
Signalrauschabstand	

AM/MW

Frequenzbereich	530-1710KHz
Zwischenfrequenz	522-1620KHz
Nutzbare Empfindlichkeit	450KHz
Signalrauschabstand	Besser als 45 dB
	40 dB

ALLGEMEINES

Stromversorgung	DC 11 -14 V
Polarität	Erde negativ
Lautsprecherimpedanz	4 Ohm
Ausgangsleistung	60 W x 4

ANMERKUNG:

Technische Änderungen ohne Meldepflicht vorbehalten.

FR

LECTEUR CD

Système	Compact disc audio system
Disques utilisables	Compact disc
Fréquence échantillonnage	44.1KHz
Nbre de quantisation bits	1bit
Fréquence	5-20,000Hz
Nombre de canaux	2 stéréo
Ratio S/B	70dB

SECTION RADIO

FM

Gamme de fréquences	87.5-107.9MHz
Fréquence intermédiaire	87.5-108MHz
Sensibilité utilisable	10.7 MHz
Séparation stéréo	Plus de 15dB à S/B 30 dB
Ratio S/B	25 dB à 1KHz
	50 dB

AM/MW

Plage de fréquences	530-1710KHz
Fréquence intermédiaire	522-1620KHz
Sensibilité utilisable	450KHz
Rapport Signal/Bruit	Supérieure à 45 dB
	40 dB

GENERAL

Alimentation	11 -14V DC
Polarité	Masse / négative
Résistance des enceintes	4 ohms
Puissance de sortie	60W x 4

REMARQUE :

Les spécifications sont susceptibles d'être modifiées sans préavis.

PT

CD Player

Sistema:	Sistema áudio CD
Tipo de disco:	CD
Frequência de Amostragem:	44.1KHz
Conversor D/A:	1bit
Resposta de frequência	5-20,000Hz
Número de canais:	2 estereo
Relação sinal/ruído:	70dB

Rádio FM

Faixa de Frequencia:	87.5-107.9MHz
Frequência Intermediária:	87.5-108MHz
Sensibilidade útil:	10.7 MHz
Separação estéreo	melhor que 15dB a S/N 30dB
Relação Sinal/Ruído	25 dB at 1KHz
	50 dB

AM/MW

Faixa de frequência:	530-1710KHz
Frequencia intermediária:	522-1620KHz
Sensibilidade útil:	450KHz
Relação Sinal/Ruído:	Melhor do que 45dB
	40dB

Geral:

Alimentação:	DC 11-14V
Polaridade:	Terra negativo
Impedância alto-falantes:	4ohms
Potência de saída:	60w x 4

Nota:

As especificações estão sujeitas a alterações sem prévio aviso.

ES

CD PLAYER

Sistema:	Compact disc audio system.
Disco:	Compact Disc.
Frecuencia Muestreo:	44.1KHz.
Cuantificación:	1bit.
Frecuencia:	5-20,000Hz.
Número de canales:	2 estereo.
Relación señal/Ruido S/N Ratio	70dB

RADIO SECCIÓN

FM

Rango Frecuencia:	87.5-107.9MHz
Frecuencia Intermedia:	87.5-108MHz
Sensibilidad Util:	10.7Mhz.
Separación estereo:	Mejor que 15dB a S/N 30dB.
S/N Ratio:	25dB a 1Khz.
	50dB.

AM/MW

Rango Frecuencia:	530-1710KHz
Frecuencia Intermedia:	522-1620KHz
Sensibilidad útil:	450KHz.
S/N Ratio:	Mejor que 45dB.
	40dB.

GENERAL

Alimentación:	DC 11-14V.
Polaridad:	Negativo a masa.
Impedancia altavoces:	4 Ohms.
Potencia de salida:	4x60W.

Nota:

Debido al rápido avance tecnológico, estas especificaciones están sujetas a cambios sin previo aviso.

IT

LETTORE CD

Sistema	Sistema di Audio CD
Tipo di disco	CD
Frequenza di campionatura	44.1KHz
N° quantizzazioni Bit	1 bit
Frequenza	5-20,000 Hz
Numero di Canali	2 stereo
Rapporto S/N	70db

SEZIONE RADIO

FM

Raggio di Frequenza	87.5-107.9MHz
Frequenza intermedia	87.5-108MHz
Sensibilità	10.7 Mhz
Separazione Stereo	migliore di 15dB a S/N 30 dB
Rapporto S/N	25dB a 1KHz
	50dB

AM/MW

Raggio di Frequenza	530-1710KHz
Frequenza intermedia	522-1620KHz
Sensibilità	450khz
Rapporto S/N	migliore di 45dB
	40dB

GENERALE

Alimentazione	Dc11 14V
Polarità	Terra negativo
Impedenza altoparlanti	4 ohms
Potenza d'uscita	4x60 Watts

Le specifiche sono soggette a cambiamenti senza alcun preavviso.

12.TROUBLE SHOOTING

Before going through the check list, check wiring connection. If any of the problems persist after check list has been made, consult your nearest service dealer.

Symptom	Cause	Solution
No power	The car ignition is not on.	If the power supply is properly connected to the car accessory terminal, switch the ignition key to "ACC"
	The fuse is blown.	Replace the fuse.
Disc cannot be loaded or ejected	Presence of CD disc inside the player.	Remove the disc in the player, then put a new one.
	Inserting the disc in reverse direction.	Insert the compact disc with the label facing upward.
	Compact disc is extremely dirty or defective disc.	Clean the disc or try to play a new one.
	Temperature inside the car is too high.	Cool off or until the ambient temperature returns to normal.
	Condensation.	Leave the player off for an hour or so, then try again.
No sound	Volume is in minimum.	Adjust volume to a desired level.
	Wiring is not properly connected.	Check wiring connection.
The operation keys do not work	The built-in microcomputer is not operating properly due to noise.	Press the RESET button. Front panel is not properly fixed into its place
Sound skips.	The installation angle is more than 30 degrees.	Adjust the installation angle to less than 30 degrees.
	The disc is extremely dirty or a defective disc.	Clean the compact disc or try to play a new one.
The radio does not work. The radio station automatic selection does not work.	The antenna cable is not connected.	Insert the antenna cable firmly.
	The signals are too weak.	Select a station manually.
ERROR 1	Mechanism Error	Press the reset button if the error code does not disappear, consult your nearest service dealer.
ERROR 2	Servo Error	Press the reset button if the error code does not disappear, consult your nearest service dealer.



If at any time in the future you should need to dispose of this product please note that Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.(Waste Electrical and Electronic Equipment Directive)